

Switch Bouton Play/Cue PIONEER CDJ 2000



CARACTERISTIQUES GENERALES :

Réf :	SAVDSG1117
Alimentation :	Secteur Français

Switch Bouton Play/Cue PIONEER CDJ 2000

Switch Bouton Play/Cue

Compatible avec :

Pioneer CDJ 2000
Pioneer CDJ 2000NXS
Pioneer CDJ 2000NXS2
Pioneer CDJ 350
Pioneer CDJ 400
Pioneer CDJ 850
Pioneer CDJ 900
Pioneer CDJ 900NXS
Pioneer CDJTOUR1
Pioneer DDJ1000
Pioneer DDJ1000SRT
Pioneer DDJ400
Pioneer DDJ800
Pioneer DDJERGO
Pioneer DDJRB

- Pioneer DDJRR
- Pioneer DDJRZ
- Pioneer DDJRZX
- Pioneer DDJS1
- Pioneer DDJSB
- Pioneer DDJSB2
- Pioneer DDJSB3
- Pioneer DDJSR2
- Pioneer DDJSZ
- Pioneer DDJSZ2
- Pioneer DDJT1
- Pioneer DJM900NXS2
- Pioneer DJMS9
- Pioneer DJMTOUR1
- Pioneer DJS1000
- Pioneer XDJ1000
- Pioneer XDJ700
- Pioneer XDJAERO
- Pioneer XDJRR
- Pioneer XDJRX
- Pioneer XDJRX2

DSG1117

Packaging :

Dimensions produit :

Données non contractuelles