

PAR 56 / 64 CAN

DMX CONTROL TABLE



4-CH CHANNEL MODE		
CHANNEL	VALUE	FUNCTION
CH1	000-255	RED (0-100%)
CH2	000-255	GREEN (0-100%)
CH3	000-255	BLUE (0-100%)
CH4	000-255	MASTER DIMMER (0-100%)

6-CH CHANNEL MODE		
CHANNEL	VALUE	FUNCTION
CH1	000-255	RED (0-100%)
CH2	000-255	GREEN (0-100%)
CH3	000-255	BLUE (0-100%)
CH4	0-255	Master dimmer (0-100%)
CH5	0-16 17-255	No function Strobe/Speed Adjust/Sound Sensitivity Adjust
CH6	0-31 32-95 96-159 160-223 224-255	No function Colour mixing RGB colour change 7 colour change Sound activation